

DOZUKI

my SKY User Manual

mySKY™ is an easy-to-use, multimedia tool that will guide you through the night sky. It's like having your own personal astronomer pointing out the wonders of the universe

Written By: Brian Sallee

INTRODUCTION


[video: http://www.youtube.com/watch?v=ZHsqOO4_Nw]



PARTS:


- [My Sky](#) (1)

Step 1 — my SKY user manual




- Follow the Quick Start Guide on the back cover to insert the batteries, plug in the earbuds and turn on mySKY. When mySKY starts up, a screen displays which offers the choice: "Instructions" or "SkyMap."

Step 2



- When you press "GoTo" on any screen, the screen will display a star map and an arrow will appear. Move mySKY in the direction the arrow is pointing
- As you move mySKY closer to the object, the arrow will get shorter and shorter

Step 3




- When you get very close to the object, a red crosshair will be displayed at the position of the object on the SkyMap.
- Move mySKY slowly to center the red crosshair in the circle at the center of the display
- The circle will then flash to let you know that you have found the object, a chime will sound and the screen will display the object page.
- Push the soft key labeled “Play” for audio descriptions and images of the object or “Info” for on-screen text data about the object. To exit a tour: Press the button labeled “End Tour.” If the “End Tour” option is not displayed, keep pressing the “Back” button until “End Tour” is displayed.

Step 4 — Example of locating an object



- If necessary, push the “Back” button until you see the SkyMap screen. The three soft Buttons are labeled **Objects**, **Options** and **Tours**.
- Press the key just below the **Objects** label. The **Objects** screen displays.
- Notice the **Solar System** option is at the top of the screen. Press the up arrow to select **Solar System**. The **Solar System** screen displays

Step 5

- Notice the “Planets” option is at the top of the screen. Press the up arrow to select “Planets.” The “Planets” screen displays.
- There are two Planets screens available. The first screen displays the four most commonly viewed planets: Venus, Mars, Jupiter, and Saturn. If you select “More,” a second Planets page will be displayed. Any time you see “More” displayed on a screen, it means you can go to another screen with more choices or information. Notice the “Saturn” option is at the bottom of the screen. Press the down arrow to select “Saturn.”

This document was last generated on 2015-07-19 11:32:45 AM.